

PROFESSIONAL USER GUIDELINES FOR PRACTICE INFECTION CONTROL AND HYGIENE IN VETERINARY EQUINE PRACTICE

Application	Frequency	Dilution per 10 litres	Contact Time
THEATRE AND STERILE PROCEDURES			
WALLS/TILES			
- Wash all surfaces from top to bottom using F10SCXD, rinse with water	Weekly	40ml/10l water	
- Wash off visible dirt (e.g. blood) using F10SCXD	When visibly soiled	40ml/10l water	
CHAIRS			
- Trigger spray using F10SC and wipe down with paper towel	Weekly	40ml/10l	Leave to dry
CUPBOARDS/SHELVES			
- Wipe down (damp dust) using F10SC and clean cloth	Weekly	40ml/10l water	Leave to dry
FLOORS			
- Sweep or rinse away all debris	Daily/after use		
- Wash thoroughly using F10SCXD & broom or HP Washer, rinse with water	Daily/after use	40ml/10l water	
- Apply F10SC through fogging machine or garden sprayer	After cleaning	40ml/10l water	Leave to dry
- Deep clean using F919SC – Apply product diluted with preferably warm water through HP washer, leave for 5 minutes, scrub lightly with broom and rinse with clean water. When using with cold water, allow contact time of 10 – 15 min before scrubbing	Monthly	200ml/10l water	5 min warm water 10 min cold water
FLOOR DRAINS			
- Remove drain covers/traps and scrub with F919SC	Weekly	200ml/10l water	5-10 min
- Flush with large volumes of clean water	Weekly		
- Pour 1 litre of diluted F10SC down drain	Weekly	40ml/10l water	
AIR SPACES			
- Fog air spaces using F10SC through fogging machine or garden sprayer OR	Weekly/After cleaning	40ml/10l water	Leave to dry
- Use F10 DISINFECTANT AEROSOL FOGGER		Ready to use	
OVERHEAD HOIST MECHANISM AND SHACKLES			
- Wash thoroughly using F10SCXD and brush or HP Washer, rinse with water		40ml/10l water	
- Apply F10SC through fogging machine or garden sprayer	Weekly	40ml/10l water	Leave to dry
- Deep clean using F919SC – Apply product diluted with preferably warm water through HP washer, leave for 5 minutes, scrub with broom and rinse with clean water. When using with cold water, allow contact time of 10 – 15 min before scrubbing	Weekly Monthly	200ml/10l water	5 min warm water 10 min cold water
EQUIPMENT(O/H LIGHTS, Q-CARTS,SUCTION BOTTLES,FACE MASKS,ET TUBES,ANAESTHETIC EQUIPMENT,ULTRASOUND PROBES,ECG MACHINE AND CABLES,DRIP STANDS)			
- Wash/wipe all surfaces from top to bottom using F10SCXD, rinse with water	Daily/Weekly/After use	40ml/10l water	Leave to dry
- Wash bottles and tubing using F10SCXD, rinse with water	After use	40ml/10l water	Leave to dry
- Apply F10SC to all surfaces	After use	40ml/10l water	Leave to dry
- Rinse bottles and tubing using F10SC OR	After cleaning	40ml/10l water	Leave to dry
- Spray out tubing using F10 DISINFECTANT AEROSOL	After cleaning	Ready to use	Leave to dry
THERMOMETERS			
- Use two sets, one in use and one stored dry			
- After use wipe with disposable paper	After use		
- Wipe using F10 WIPES or spray with F10SC and wipe with paper towel	After use	40ml/10l water	
SCOPES(ENDOSCOPES/GASTROSCOPES/ARTHROSCOPES)			
- Follow manufacturers instructions with regards to rinsing procedure after use, as well as use of enzymatic agent	After every use		
- Rinse for 1 minute. Wash using F10SCXD for 10 minutes if mechanical (5 minutes if ultrasonic), rinse for 1 minute	After every use	100ml/10l water	
- Soak in F10 STERILANT (RTU) for 10 minutes, rinse with sterile water or use without rinsing OR	After every use	Ready to use	
- Soak in F10SC (1:100) for 10 minutes, rinse with sterile water or use without rinsing	After every use	100ml/10l water	
- NOTE: If a gluteraldehyde had been used to disinfect the instrument, it must be thoroughly washed and wiped with alcohol before immersed in F10. A reddish residue may form on the instrument as the result of the interaction between aldehyde and F10. This will not damage the Instrument and can be avoided by thorough cleansing to remove aldehyde residues			
ELECTRIC RAZORS AND BLADES			
- Scrub with nylon brush using F10SCXD, rinse with water	After every use	40ml/10l water	

Application	Frequency	Dilution per 10 litres	Contact Time
<ul style="list-style-type: none"> - Trigger spray using F10SC - Apply blade wash/lubricant - Store dry 	After cleaning	40ml/10l water	Leave to dry
ENDOTRACHEAL TUBES			
<ul style="list-style-type: none"> - Wash thoroughly with F10SCXD (rinse lumen thoroughly to clear away mucous) - Soak in F10SC - OR soak in F10 STERILANT (RTU) - Rinse with sterile water OR remove without rinsing - Store clean and dry 	After every use After cleaning After cleaning	40ml/10l water 40ml/10l water Ready to use	30 minutes 10 minutes
NEEDLES, SYRINGES, I/V CATHETERS, DRIP SETS, SUTURE MATERIAL, NAIL BRUSHES			
<ul style="list-style-type: none"> - Single use is safest and best practice! - Do not store in disinfectant 	After every use	100ml/10l water	10 minutes
<ul style="list-style-type: none"> - Wash using F10SCXD, rinse with water - Soak in F10 STERILANT(RTU) - Rinse with sterile water OR Remove without rinsing - Store clean and dry 	After every use	Ready to use	10 minutes
INSTRUMENTS			
<ul style="list-style-type: none"> - Cover soiled instruments with sterile damp swab to avoid blood drying on them - Wash thoroughly in lukewarm water and F10SCXD using a soft nylon brush - Dry thoroughly and lubricate with instrument lubrication. Dry - Sterilize through moist steam or cold sterilization process 	During procedure After procedure	100ml/10l water	
COLD STERILIZATION			
<ul style="list-style-type: none"> - Fully immerse clean and dry instruments in fresh solution of F10 STERILANT(RTU) - Remove using sterile instrument or wearing sterile gloves(rinse with sterile water OR use without rinsing) - Use immediately or store in sterile container 	After cleaning and when required	Ready to use	10 minutes
AIRCON SYSTEMS			
<ul style="list-style-type: none"> - Remove filters, apply F919SC, leave for 10 min, scrub lightly, rinse with water - Immerse filter in F10SC - F10SC can also be sprayed or fogged into air ducting 	Monthly Monthly Monthly	200ml/10l water 40ml/10l water 40ml/10l water	10 minutes Leave to dry Leave to dry
WASTE BINS			
<ul style="list-style-type: none"> - Remove plastic liner, tie closed and discard - Wash down using F10SCXD, rinse with water - Trigger spray with F10SC inside new liner as well as top of bin 	Daily Daily	40ml/10l water 40ml/10l water	Leave to dry
TELEPHONES/LIGHT SWITCHES/DOOR HANDLES			
<ul style="list-style-type: none"> - Trigger spray using F10SC onto paper towel or clean cloth and wipe down 	Daily/weekly/ when soiled	40ml/10l water	Leave to dry
WORK SURFACES /THEATRE TABLE/ INSTRUMENT TROLLEYS/THEATRE TABLE MATTRESS)			
<ul style="list-style-type: none"> - Wash visible debris off with clean water - Wipe down with F10SC in trigger spray bottle and clean cloth - Wash all surfaces from top to bottom using F10SCXD, rinse with clean water - Deep clean using F919SC – Apply product diluted with preferably warm water through HP washer, leave for 5 minutes, scrub lightly with broom and rinse with clean water. When using with cold water, allow contact time of 10 – 15 min before scrubbing 	After use/Daily Weekly/when soiled Monthly	40ml/10l water 40ml/10l water 200ml/10l water	Leave to dry Leave to dry 5-10 minutes
SOAP DISPENSERS			
<ul style="list-style-type: none"> - Fill dispensers halfway. DO NOT TOP UP - When bottle is empty, wash using hot water and F10SCXD - Trigger spray nozzles using F10SC 	Before filling Daily/after use	40ml/10l water 40ml/10l water	Leave to dry
BASINS			
<ul style="list-style-type: none"> - Wash thoroughly with F10SCXD, rinse with water - Trigger spray with F10SC 	Daily/after use Daily/after use	40ml/10l water 40ml/10l water	Leave to dry
HAND HYGIENE Sterile & invasive procedures			
<ul style="list-style-type: none"> - Wash hands with F10 HAND SCRUB & luke warm water, while keeping hands higher than elbows& using friction for 2 minutes,rinse,close tap with elbows,dry hands with sterile towel from fingers to elbows 	Before procedure for 2 minutes	4ml	

PROFESSIONAL USER GUIDELINES FOR PRACTICE INFECTION CONTROL AND HYGIENE IN VETERINARY EQUINE PRACTICE

Application	Frequency	Dilution per 10 litres	Contact Time
<p>General practice</p> <ul style="list-style-type: none"> - Wash hands with F10 ANTISEPTIC LIQUID SOAP using friction for 30 seconds, rinse, dry hands with paper towel & use paper to close tap - Use F10 HAND GEL as alternative for decontamination of hands 	<p>Between cases/after contamination for 30 sec</p> <p>Between cases/after contamination. Leave to dry (30 sec)</p>	<p>4ml</p> <p>1 ml</p>	
PATIENT SKIN PREPARATION			
<ul style="list-style-type: none"> - Clip wide area neatly and as short as possible using clean no 40 blade - Wash area thoroughly using F10 HANDSCRUB OR F10 ANTISEPTIC LIQUID SOAP and lukewarm water, dab away excess moisture. Repeat until no visible dirt is left on skin - Spray F10SKIN PREP (RTU) and wipe with clean swab. Repeat - Move patient onto operating table, spray surgical site with F10 SKIN PREP (RTU) 	<p>Before procedure</p> <p>Before procedure</p> <p>Before procedure</p> <p>Before procedure</p>	<p>4ml (for 30 sec)</p> <p>Ready to use</p> <p>Ready to use</p>	<p>30 sec</p> <p>30 sec</p>
PROTECTIVE CLOTHING (SCRUBS, THEATRE GOWNS, OVERALLS, DRAPES)			
<ul style="list-style-type: none"> - Soak item in F10SCXD prior to washing - Wash in washing machine, hang in sun to dry or use tumble dryer - To eliminate persistent odours, add approximately 100ml of F10 ODOUR ELIMINATOR to wash water 	<p>After use</p> <p>Daily for a week or as required</p>	<p>40ml/10l water</p> <p>Ready to use</p>	<p>30 minutes</p>
CLEANING EQUIPMENT			
<ul style="list-style-type: none"> - Use brooms & brushes with nylon bristles & plastic backing where possible - Rinse clear of all debris - Wash brooms, brushes, cloths thoroughly in F10SCXD, hang to dry (do not rinse) - Scrub buckets & mop trolleys with F10SCXD, rinse with water - Start shift with clean and dry equipment 	<p>End of shift</p> <p>End of shift</p> <p>End of shift</p>	<p>40ml/10l water</p>	<p>Leave to dry</p>
X-RAY EQUIPMENT (LEAD GLOVES AND GOWNS)			
<ul style="list-style-type: none"> - Wash using F10SCXD if visibly soiled - Trigger spray using F10SC and wipe down with paper towel. 	<p>If visibly soiled</p> <p>Daily</p>	<p>40ml/10l water</p> <p>40ml/10l water</p>	<p>Leave to dry</p>
INSECT CONTROL			
<ul style="list-style-type: none"> - Spray walls and ceilings in areas where fly control is required lightly with F10 ENVIRONMENTAL SPRAY WITH INSECTICIDE, repeat daily for 3 days, thereafter every 10 – 14 days or as required 	<p>Daily for 3 days</p> <p>Every 14 days</p> <p>As required</p>	<p>Ready to use</p>	

Application	Frequency	Dilution per 10 litres	Contact Time
STABLE AREA			
STABLES (WALKWAYS/PASSAGES)WALLS & DOORS			
- Muck out and remove debris	Daily		
- Wash all surfaces from top to bottom using F10SCXD, rinse with water	Weekly/After discharge	40ml/10l water	
- Apply F10SC to all surfaces through fogging machine or garden sprayer	After cleaning	40ml/10l water	Leave to dry
FLOORS			
- Wash using F10SCXD with broom or HP Washer, rinse with water	Monthly/After discharge	40ml/10l water	
- Apply F10SC to all surfaces through fogging machine or garden sprayer	After cleaning	40ml/10l water	Leave to dry
SPRING CLEAN			
- Deep clean using F919SC – Apply product diluted with preferably warm water through HP washer, leave for 5 minutes, scrub lightly with broom and rinse with clean water. When using with cold water, allow contact time of 10 – 15 min before scrubbing	With change of each season	200ml/10l water	5-10 minutes
- Apply F10SC to all surfaces through fogging machine or garden sprayer	After deep cleaning	40ml/10l water	Leave to dry
WATER & FOOD TROUGHS / BUCKETS			
- Rinse thoroughly, apply F919SC, leave for 10 min, scrub lightly, rinse with water	After discharge/Weekly	200ml/10l water	
- Apply F10SC to all surfaces through fogging machine or garden sprayer	After discharge/Weekly	40ml/10l water	Leave to dry
CRUSHES/PROCEDURE AREAS			
- Remove debris	After use	40ml/10l water	
- Wash/Scrub using F10SCXD with broom or HP Washer, rinse with water	After use	40ml/10l water	
- Apply F10SC to all surfaces through fogging machine or garden sprayer	After use / Weekly	40ml/10l water	Leave to dry
CLEANING EQUIPMENT			
- Use brooms & brushes with nylon bristles & plastic backing where possible	End of shift		
- Rinse clear of all debris	End of shift	40ml/10l water	Hang to dry
- Wash brooms, brushes, cloths thoroughly in F10SCXD, hang to dry (do not rinse)			
- Scrub buckets & mop trolleys with F10SCXD, rinse with water			
- Start shift with clean and dry equipment	Weekly	40ml/10l water	
DRAINS			
- Remove drain covers/traps & scrub with F919SC	Weekly	200ml/10l water	
- Rinse with water			
- Flush with large volumes of clean water	Weekly	4ml/1l water	
- Pour 1 l of diluted F10SC down drain			
EQUIPMENT (HALTERS, TACK, SADDLE CLOTHS.GROOMING EQUIPMENT)			
- Apply F10SC to all surfaces through trigger spray bottle	Between horses	40ml/10l water	Leave to dry
- Wash all surfaces from top to bottom using F10SCXD, rinse with water, hang out to sun dry	Weekly	40ml/10l water	Hand to dry
SEASONAL INSECT CONTROL & HYGIENE			
- Spray walls and ceilings in areas where fly control is required lightly with F10 ENVIRONMENTAL SPRAY WITH INSECTICIDE, repeat daily for 3 days, thereafter every 10 – 14 days or as required	Daily for 3 days Every 14 days As required	Ready to use	
HAND HYGIENE			
SOILED/VISIBLY DIRTY HANDS			
- Wash hand with F10 ANTISEPTIC LIQUID SOAP using friction for 30 sec, rinse, dry thoroughly	When visibly dirty	4ml	30 sec
BETWEEN HORSES			
- Dispense F10 HAND GEL onto hands, rub over all surfaces, allow to air dry OR	Between handling horses, when hands not visibly soiled	1ml	Leave to dry
- Spray hands with F10SC and leave to dry(use trigger spray bottle)		4ml/1l water	
TRANSPORT			
AFTER USE			
- Wash all surfaces from top to bottom using F10SCXD, rinse with water	After each use	40ml/10l water	
- Apply F10SC to all surfaces through fogging machine or garden sprayer	After cleaning	40ml/10l water	Leave to dry

Application	Frequency	Dilution per 10 litres	Contact Time
ISOLATION IN CASE OF INFECTIOUS DISEASES E.G. SALMONELLA, STRANGLES			
<ul style="list-style-type: none"> • HAVE DEDICATED STAFF ASSIGNED TO ISOLATED CASES • HAVE DEDICATED TACK & GROOMING EQUIPMENT • MAKE USE OF FOOT BATHS • CORRECT HAND HYGIENE! • DO NOT USE HIGH PRESSURE WASHER 			
ENVIRONMENT STABLES: WALLS & DOORS & WALKWAYS/BREEZEWAYS			
<ul style="list-style-type: none"> - "Spot clean" contaminated areas in stable using F10SCXD, rinse with water - Wash all surfaces from top to bottom using F10SCXD, rinse with water. DO NOT use high pressure cleaner for infectious cases - Apply F10SC to all surfaces through garden sprayer or fogging machine - Remove all bedding and place in plastic bags, tie closed - Deep clean using F919SC – Apply product diluted with preferably warm water through HP washer, leave for 5 minutes, scrub lightly with broom and rinse with clean water. When using with cold water, allow contact time of 10 – 15 min before scrubbing 	Daily After discharge/Weekly After cleaning Once horse has been removed After discharge	80ml/10l water 80ml/10l water 80ml/10l water 200ml/10l water 200ml/10l water	Leave to dry Leave to dry Leave to dry
WATER & FOOD TROUGHS/BUCKETS			
<ul style="list-style-type: none"> - Deep clean using F919SC – Apply product diluted with preferably warm water through HP washer, leave for 5 minutes, scrub lightly with broom and rinse with clean water. When using with cold water, allow contact time of 10 – 15 min before scrubbing - Scrub using F10SCXD and nylon brush, rinse with water - Apply F10SC to all surfaces through fogging machine or garden sprayer 	After discharge/Weekly After discharge/Weekly	200ml/10l water 80ml/10l water 80ml/10l water	5-10 minutes Leave to dry
FOOTBATHS			
<ul style="list-style-type: none"> - Scrub using F10SCXD, rinse with water - Fill with F10SC to level of at least 15cm 	Daily Replace daily or when visibly soiled	80ml/10l water 80ml/10l water	
EQUIPMENT HALTERS, TACK, SADDLE CLOTHS, GROOMING EQUIPMENT & CLEANING EQUIPMENT			
<ul style="list-style-type: none"> - Apply F10SC to all surfaces through trigger spray bottle - Wash all surfaces from top to bottom using F10SCXD, rinse with water 	After use Weekly & after horse removed from isolation	80ml/10l water 80ml/10l water	Leave to dry
HAND HYGIENE AFTER HANDLING HORSE, EQUIPMENT			
<ul style="list-style-type: none"> - Wash hand with F10 HAND SCRUB using friction for 30 sec, rinse, dry thoroughly 	After making contact and before handling other horses or their equipment.	4ml	30 sec
BETWEEN HORSES			
<ul style="list-style-type: none"> - Dispense F10 HAND GEL onto hands, rub over all surfaces, allow to air dry OR - Spray hands with F10SC and leave to dry(use trigger spray bottle) 	Between handling horses, when hands not visibly soiled	1ml 4ml/1l water	Leave to dry
TRANSPORT AFTER USE			
<ul style="list-style-type: none"> - Wash all surfaces from top to bottom using F10SCXD, rinse with water - Apply F10SC to all surfaces through fogging machine or garden sprayer 	After each use before transporting other horses.	80ml/10lwater 80ml/10lwater	Leave to dry

NOTE: FOR FULL INFORMATION ON PRODUCTS MENTIONED ABOVE REFER TO OUR PRODUCT INFORMATION LEAFLETS.

© Health and Hygiene (Pty) Ltd Oct 2009 update